

Technical Accessory Guides (TAGs)

For Associates, Resellers, ISVs and Alliance Partners Global



Version: All

Will show products that are known to be available for sale and discontinued products along with suggested replacements, when known

Need to provide an update or change? Contact mailto:pgw786@zebra.com







RS2100 Series Technical Accessory Guide



NOTE: This document is only for general reference. Solutions Pathway and related PMBs should be used for product availability, pricing, and final solution selection.

* Zebra does not endorse or specifically recommend any third-party products, accessories, or hardware. ZEBRA DISCLAIMS ANY AND ALL LIABILITY, INCLUDING ANY EXPRESS OR IMPLIED WARRANTIES, WHETHER ORAL OR WRITTEN, FOR SUCH THIRD PARTY PRODUCTS, ACCESSORIES, OR HARDWARE. THE CUSTOMER ACKNOWLEDGES THAT NO REPRESENTATION HAS BEEN MADE BY ZEBRA AS TO THE FITNESS OF THE THIRD-PARTY PRODUCTS, ACCESSORIES, OR HARDWARE FOR THE CUSTOMER'S INTENDED PURPOSE.

| Cradles/Charging | | | | | | | |
|-------------------|-------------|------------------------|---|--|--|--|--|
| Part Number | Picture | Description | Notes | Required Items | | | |
| CRD-RS2X-2SCHG-01 | IEBRA IEBRA | 2-Slot Charging Cradle | ➤ Will charge up to 2 RS2100 units ➤ Hand mount must be removed from RS2100 to dock in cradle. Cradle connects to contacts on the bottom of scanner. ➤ Status lights on the RS2100 unit indicate its charging status. ➤ Cradle can be easily mounted vertically or horizontally on tabletops, walls, poles, etc. using zip ties or screws (not included). ➤ Charge times (at room temperature when using PWR-WUA5V12Wxx Power Adapter): 0-90% in less than 2.5 hours | ►USB Power Adapter (PWR-WUA5V12W0US - or country specific version) ►USB-C Cable (CBL-TC5X-USBC2A-01) | | | |
| BT-RS5X6-DNGL-01 | | Bluetooth Adapter | ▶ Allows RS2100 to be easily connected with hosts that do not have a Bluetooth radio for direct communication. ▶ Pairing barcode on adapter is scanned to instantly pair with the RS2100. ▶ Up to 7 scanners can be paired per adapter. ▶ Paging button on adapter will trigger all paired scanners to beep, ideal for locating misplaced/hidden scanners. ▶ Adapter is powered from host via USB. ▶ Adapter can be easily mounted vertically or horizontally on tabletops, | ►USB Scanner Cable (CBA-U46-S07ZAR) | | | |

walls, poles, etc. using zip ties or screws (not included).

| KT-RS5X6-BTDCBL-01 | | Bluetooth Adapter KIT | ▶ Allows RS2100 to be easily connected with hosts that do not have a Bluetooth radio for direct communication. ▶ Pairing barcode on adapter is scanned to instantly pair with the RS2100. ▶ Up to 7 scanners can be paired per adapter. ▶ Paging button on adapter will trigger all paired scanners to beep, ideal for locating misplaced/hidden scanners. ▶ Adapter is powered from host via USB. ▶ Adapter can be easily mounted vertically or horizontally on tabletops, walls, poles, etc. using zip ties or screws (not included). ▶ Kit includes: - Bluetooth Adapter (BT-RS5X6-DNGL-01) - USB Scanner Cable (CBA-U46-S07ZAR) | |
|---|--|--|---|---|
| CBA-U46-S07ZAR | | Shielded USB Cable: Series A Connector, 7ft. Straight | ► Used with Bluetooth Adapter (BT-RS5X6-DNGL-01) | |
| STB3678-C100F3WW STB3678-C100F3CN (for use in mainland China only) | THE STATE OF THE S | Communication Cradle | ► Allows RS2100 to be easily connected with hosts that do not have a Bluetooth radio for direct communication. ► Pairing barcode on Cradle is scanned to instantly pair with the RS2100. ► Up to 7 scanners can be paired per cradle. | ► Host communication cable and possibly a power supply depending on the host cable type. See 36XX Series Scanner accessory document for cable and power supply options |
| FLB3678-C100F3WW FLB3678-C100F3CN (for use in mainland China only) | Tana Para Para Para Para Para Para Para P | Sealed Communication Cradle | ► Allows RS2100 to be easily connected with hosts that do not have a Bluetooth radio for direct communication. ► Pairing barcode on Cradle is scanned to instantly pair with the RS2100. ► IP65 sealed for installations requiring wash-down (i.e. forklift installations). ► Up to 7 scanners can be paired per cradle. | ► Host communication cable and possibly a power supply depending on the host cable type. See 36XX Series Scanner accessory document for cable and power supply options |
| Soft Goods | | | | |
| Part Number | Picture | Description | Notes | Required Items |

| SG-RS2X-HMTRA-01 (single) SG-RS2X-HMTRA-10 (10 pack) | | Hand Mount With Embedded Trigger, Right Hand | ► Required to be used with each RS2100 unit. A Hand Mount is not included with the scanner. ► One size fits all | | | | |
|---|----------------------------|--|--|----------------|--|--|--|
| SG-RS2X-HMTLA-01 (single) SG-RS2X-HMTLA-10 (10 pack) | | Hand Mount With Embedded Trigger, Left Hand | ► Required to be used with each RS2100 unit. A Hand Mount is not included with the scanner. ► One size fits all | | | | |
| Power Cords/Power Su | Power Cords/Power Supplies | | | | | | |
| Part Number | Picture | Description | Notes | Required Items | | | |
| PWR-WUA5V12W0US (US plug style) PWR-WUA5V12W0GB (UK plug style) PWR-WUA5V12W0EU (EU plug style) PWR-WUA5V12W0AU (Australia plug style) PWR-WUA5V12W0CN (China plug style) PWR-WUA5V12W0IN (India plug style) PWR-WUA5V12W0KR (Korea plug style) PWR-WUA5V12W0BR (Korea plug style) PWR-WUA5V12W0BR (Brazil plug style) PWR-WUA5V12W0LA (Argentina/Chile/Mexico plug styles) | | USB Power Supply | ► Used with USB-C Cable to power 2- Slot Cradle (CRD-RS2X-2SCHG-01) ► Provides higher current (2.5A) for faster charging ► 100-240 VAC, 5 V, 2.5 A | | | | |
| CBL-TC5X-USBC2A-01 | | USB-C cable | ► Used to power 2-Slot Cradle (CRD-RS2X-2SCHG-01). ► USB-A to USB-C cable | | | | |